

PRINTING INSTRUCTIONS

To print this document, you can right-click the screen, and then click print to print from your browser. You can also download the document to your computer, open it in Adobe Reader or another program, and print using that program.

Make sure you select the option to print this document at its actual size. Failure to do so may result in an incorrect size for this template.

To confirm that you have printed at actual size, use the ruler graphic below. Each division on the graphic should be 1 inch in length when measured with a ruler or measuring tape.

**EACH SECTION OF THE RULER GRAPHIC
SHOULD MEASURE 1 INCH WHEN THIS
DOCUMENT IS PRINTED**

MOUNTING INSTRUCTIONS

Once you have printed the mounting template, follow these instructions to drill holes for your camera.

1. Cut around the outline of the camera template.
2. Tape the template to the location you want to mount your camera.
3. Use a 1 1/2" drill bit to drill through the paper and wall or ceiling for the cable connection.
4. Use a 1/4" drill bit to drill through the paper and wall or ceiling to create the holes for the plastic anchors.
5. Remove the template from the location.
6. Insert the plastic anchors into the smaller holes.
7. Follow the installation instructions included with your camera.

